



## System Time on any Partner System

If you hear a waive-off (siren) tone, you are on a Legend or MAGIX system.

**This System Programming procedure sets the time that appears on system display phones.**

Enter the time in 24-hour notation. In this scheme, the hours of the day are 0000 (12 midnight) to 2359 (11:59 p.m.). Since each time must have four digits, use leading zeros when necessary. For example, to set the time to 9:00 a.m., enter 0900. For 4:45 p.m., enter 1645.

The time appears on system display phones as a.m. or p.m. (not in 24-hour notation).

**To change the System Time using a display phone at extension 10 or 11:**

1. Press [Feature] [0] [0].
2. Press [System Program] (Left Intercom button).
3. Press [System Program] (Left Intercom button).
4. Press [#] [1] [0] [3].
5. Enter the time in 24-hour notation. For example, to set the time to 2:15p.m., press 1415.

A display similar to the following appears:

- A. System Time
- B. Data 1415

Note: The time will appear on system display phones as 2:15p.

6. Select another procedure or press [Feature] [0] [0] to exit programming mode.

If you encounter problems programming this feature:

- A. You are not programming the from extension 10 or 11. To determine the extension you are using, press [Feature] [0] [0]. The display should show "Programming ext. XX".
- B. You are not using a display phone.
- C. The Partner phone you are using is on a MERLIN Legend (R7) or MERLIN MAGIX system. How can you determine if this is the case? Pick up the handset and select a line button. Dial [Feature] [#] [1]. If you hear a series of beeps, you are on a Partner system.